

Low/Reverse Switch Checkball Sleeve Kit


Part No.

92835-41K

- Outboard Sleeve
- Inboard Sleeve
- Checkballs (2)

1 Extra

Chrysler 45RFE, 545RFE, 65RFE, 66RFE, 68RFE



1. Disassembly

- Remove accumulator retaining plate on valve body.
- Remove and discard OE retaining clip, end plug, and valve.

2. Installation & Assembly

- Ensure all debris has been removed from valve bore and body.
- Install Sonnax inboard sleeve.
- Install Sonnax checkball into outboard sleeve.
- Install Sonnax outboard sleeve/checkball into bore.
- Reinstall OE accumulator retaining plate.

3. Final Testing

Vacuum testing at the port(s) indicated holds the recommended minimum 18 in-Hg (**Figure 1**).

NOTE: During vacuuming testing, user must manually shuttle the OE valve to whichever worm track they are testing in order to see results.

