TRANSMISSION PARTS


Instructions

## **GM TH400, TH425**

## **Boost Valve Kit**

# Part No. 34910-01K

- Valve
- Sleeve
- O-Rings (2)



#### 1. Disassembly

- a. Remove and discard OE boost sleeve and valve.
- b. Save OE retaining ring for reuse.

### 2. Installation & Assembly

- a. Lubricate all pieces of Sonnax kit.
- b. Place Sonnax O-rings into outboard grooves of Sonnax sleeve (main photo).
- c. Insert Sonnax valve into Sonnax sleeve with the long stem facing out.
- d. Carefully push Sonnax sleeve assembly (open end first) into the pump body only deep enough to reinstall the OE retaining ring.
- e. Reinstall OE retaining ring on the pump body.